

# VANTAGE®



## VANTAGE®

THESE INSTRUCTIONS DO NOT PURPORT TO COVER ALL DETAILS OR VARIATIONS IN THE EQUIPMENT AND DO NOT CLAIM TO PROVIDE FOR EVERY POSSIBLE CONTINGENCY MET IN CONNECTION WITH INSTALLATION, OPERATION, OR MAINTENANCE. THE MATERIAL IN THIS MANUAL IS FOR INFORMATIONAL PURPOSES ONLY. THE PRODUCTS IT DESCRIBES ARE SUBJECT TO CHANGE WITHOUT PRIOR NOTICE, DUE TO THE MANUFACTURER'S CONTINUOUS DEVELOPMENT PROGRAM.


VANTAGE KITES INTERNATIONAL B.V. MAKES NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THIS MANUAL OR WITH RESPECT TO THE PRODUCTS DESCRIBED HEREIN AND SHALL NOT BE LIABLE FOR ANY DAMAGES, LOSSES, COSTS OR EXPENSES, DIRECT, INDIRECT OR INCIDENTAL, CONSEQUENTIAL OR SPECIAL, ARISING OUT OF, OR RELATED TO THE USE OF THIS MATERIAL OR THE PRODUCTS DESCRIBED HEREIN.

VANTAGE - MAIDEN FLIGHT MANUAL - EN - V1.0 - 9/2019

### MAIDEN FLIGHT #CHECKLIST


DEVELOPMENT PROGRAM

# MAIDEN FLIGHT CHECKLIST



**01.**  
**CHECK & VALIDATE THE BRIDLES DEFAULT SETTING**

CHECK BRIDLES TO MATCH THE DEFAULT FLIGHT MODE.  
 ADJUST WHEN NECESSARY.



**02.**  
**TIGHTEN & DOUBLE CHECK BRIDLE CONNECTION PIGTAILS**

MAKE SURE ALL BRIDLE CONNECTION PIGTAILS ARE TIGHTENED AND CROSS CHECKED. ALWAYS DOUBLE CHECK AND TIGHTEN YOUR LOOP KNOT CONNECTION WITH MAXIMUM CARE.

**CAUTION!**  
 CHANGING BRIDLE POSITIONS MUST BE DONE WITH MAXIMUM CARE AND ACCURACY, TO AVOID UNWANTED FLIGHT BEHAVIOUR RESULTING IN UNSAFE EVENTS.

